

## 3 Easy Steps

**1** Place Pressure<sup>x</sup><sup>®</sup> surface sensor film at the actual contact point of your heat sink interface.

**2** Bolt or clamp the heat sink in place to apply the load and then remove.

**3** The color Pressure<sup>x</sup><sup>®</sup> surface pressure film turns indicates the precise PSI level.

