



Measure-

ment





Product used: Prescale (Extreme Low Pressure 4LW, Ultra Super Low Pressure LLLW)





Prescale is inserted between the heating and pressurizing roll

Application 1 Without rotating the rolls, the Prescale is nipped and pressure uniformity is checked according to the width of the colored lines.

While rotating the rolls to pass the Prescale between the heating and pressurizing rolls, Application 2 pressure distribution is checked for nip width and length.

Pressure distribution can also be checked while rotating the rolls at the actual temperature used for fixing.





*Note that the specifications and performance data described in this catalog are subject to change without notice for the purpose of improvement. Since images are used for illustration purposes, they may differ slightly from the actual product.



Sensor Products Inc. 300 Madison Avenue Madison, NJ 07940 USA Phone: 1.973.884.1755 Fax: 1.973.884.1699 www.sensorprod.com



Sensor Products, Inc. is an authorized distributor for Fujifilm Prescale® in the U.S.A., Canada, Mexico & the Caribbean only. Fujifilm Prescale® is a registered trademark of Fujifilm Corp. ©2014 Sensor Products, Inc. Updated 04-15-2014